

WARNING ORGAN DOLLY SAFETY

Any piece of equipment can be dangerous if not operated properly. **YOU** are responsible for the safe operation of this equipment. The operator must carefully read and follow any warnings, safety signs and instructions provided with or located on the equipment. Do not remove, defeat, deface or render inoperable any of the safety devices or warnings on this equipment. **IF** any safety devices or warnings have been removed, defeated, defaced, or rendered inoperable, **DO NOT USE THIS EQUIPMENT!!!**

DANGER: This equipment has multiple pinch points that can cause dismemberment or death. Keep hands, feet and all other body parts clear at all times.

⚠ WARNING: This product contains Chromium from steel products which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65warnings.ca.gov

Warning use extreme caution when transporting cargo to avoid loss of load resulting in damage to dolly, personal injury and/or property damage. Always keep others away from load & dolly while lifting, transporting & lowering loads.

- Do not exceed 1,000 lb. rated capacity.
- Dolly is designed for use in pairs by two persons only for safe operation.
- Always use on smooth, level, finished floors only.
- Do not use dolly on a slope, a ramp, or uneven floors.
- Always keep all people clear from load & dolly while lifting, lowering, or transporting load.
- Failure to comply with all these warnings may result in loss of load, damage to dolly, personal injury and/or property damage.

IMPORTANT SAFETY RULES TO FOLLOW

Position each dolly evenly & fully under opposite ends of the object to be lifted.

There are four nylon straps included to secure the cargo to the dolly. Wrap each nylon strap completely around the load & tighten securely through strap hooks. Always use all four nylon straps to secure cargo.

With each dolly fastened securely under opposite ends of the object to be lifted lower the lifting lever with one foot or both feet. Use the wooden handles for additional leverage if necessary, to press lifting lever down.

After each dolly has been raised successfully, use wooden handles to steer and/or push & pull dolly to desired location.

To lower load, use foot to raise lifting lever carefully on each dolly.

Remove nylon straps & remove each dolly from opposite ends of the cargo.

If the person receiving this handout will not be the user of the equipment, forward these instructions to the operator. **IF** there is any doubt as to the operation or safety of the equipment, **DO NOT USE!!! CALL A TOOL SHED IMMEDIATELY!!! FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN INJURY OR DEATH**